




KLEINN TECH

HOW TO WIRE A DIRECT DRIVE COMPRESSOR 12 VOLT SIGNAL FROM HORN BUTTON

FACTORY HORN BUTTON SENDS 12 VOLT SIGNAL
WHEN HORN BUTTON IS DEPRESSED



Disconnect wire(s) from factory horn under hood or in grill. Check to see if wire(s) have:

1. Constant 12 volts
2. 12 volts only when horn button pressed
3. Constant ground
4. Ground only when horn button is depressed

Note this for proper connection of the direct drive compressor.

This diagram is for wiring a 6126 or 6127 horn with direct drive compressor (P/N DD1)